BATTERY CHARGING *QUICK STEPS*

For SpeedCharge™ Model SC-7500A Battery Charger with Engine Start and Tester

SAFETY FIRST!

For Safety Warning Instructions, refer to Owner's Manual

Note: A marine (boat) battery installed in a boat must be removed and charged on shore.

Steps To Take Before Using Your Battery Charger

See pages 3 & 4 of the Owner's Manual for all cautionary warnings.

1. Make sure to use a grounded 120V AC electrical outlet.
2. Keep hands, hair, clothing and jewelry clear of fan blades, belts, pulley and other engine parts.
3. Keep the power cord and output cords away from the hood, door and/or moving engine parts.
4. Wear safety glasses.
5. Charge battery in a well-ventilated area.

Getting Your Battery Ready

1. If necessary, clean the battery terminals as well as possible. Wear rubber gloves and safety glasses to avoid contact with battery acid.
2. For batteries with removable vent caps, see page 4 of Owner's Manual for details.

Connecting Your Battery Charger

1. Attach RED clamp to positive (+) battery terminal. Refer to picture. (Negative Ground System)
2. Attach BLACK clamp to negative (-) ground on an unpainted frame part or engine block of vehicle.
3. Then, plug charger into a 120V AC electrical outlet. Simply reverse the steps to disconnect.



Testing Your Battery

1. Press the BATTERY TYPE button to select your battery type: 12V STANDARD; or 12V AGM, OR 12V GEL CELL.
2. Read the voltage on the digital display or press the DIGITAL DISPLAY button to set the tester to BATTERY % to determine the charge left in your battery.
   Note: If the BATTERY SIZE button has been pressed and the CHARGING LED is on, the SC-7500A is no longer in Test Mode. To change from Charge Mode back to Test Mode, press the BATTERY SIZE button until all three charge rate LEDs are off. See page 10 of the Owner's Manual for details.

OVER

00-99-000658/1107

Using Your Alternator Tester

1. Start the engine and turn on the vehicle's headlights.
2. Read the voltage on the digital display or press the DIGITAL DISPLAY button to set the tester to ALTERNATOR %. The alternator percent will display a range from 0 to 199. See page 11 of the Owner's Manual for details.

Using Your Engine Starter

1. Press the BATTERY SIZE button until the ENGINE START LED glows.
2. Crank the engine for no more than 5 seconds until it starts. The digital display will count down from 5 to 0 seconds.
3. If engine does not start within 5 seconds, stop cranking the engine. The SC-7500A needs to cool 3 minutes between crankings. It will automatically count down from 180 to 0 seconds, or 3 minutes. No power is delivered to the battery during this time.
4. During the 3-minute cool down period, the ENGINE START LED will blink. After the cool down period ends and the charger is ready for another attempt to crank the engine, the ENGINE START LED light will stay on continuously.
5. If necessary, repeat steps 2 through 4 until engine starts. After engine starts, unplug 120V AC electrical power cord before disconnecting the output clamps from the battery. See page 6 of the Owner's Manual for details.

Charging Your Battery

1. Press the BATTERY TYPE button to select your battery type: 12V STANDARD; 12V AGM or 12V GEL CELL.
2. Press the BATTERY SIZE button to select the rate appropriate for the battery being charged: SMALL BATTERY or MEDIUM TO LARGE BATTERY. The CHARGING LED glows when charging begins and shuts off automatically after the battery is charged.
   Note: If the BATTERY SIZE button is pressed enough times, it is possible for no charge rate to be selected. If all the BATTERY SIZE LEDs are off, then no rate is selected and the SC-7500A is in Test Mode. To return to Charge Mode, press the BATTERY SIZE button until one of the charge rate LEDs glows. See page 4 of the Owner's Manual for details.
3. The green CHARGED LED will turn on after the battery is charged and the charger will automatically change to Maintain Mode. See page 7 of the Owner's Manual for details.
4. To immediately use your vehicle, unplug the battery charger from the 120V AC electrical outlet, remove the battery charger's clamps from the vehicle and have a great day!

SEE OWNER'S MANUAL FOR MORE DETAILS.

Schumacher® ELECTRIC CORPORATION

Questions? Call Customer Service
7 am to 4:30 pm CST Monday through Friday

1-800-621-5485